



### MODELLO PERFORMANCE - REGOLARE LA CORDA



SPINGI LA CORDA FUORI DAL MANICO

STEP 01



TENENDO LA CORDA DALL'ESTRE MITÀ, TIRARE LA BOCCOLA INDIETRO CON DECISIONE PER LIBERARE LA PINZA

STEP 02



MUOVERE LA PINZA PER REGOLARE LA CORDA ALLA LUNGHEZZA DESIDERATA. PUOI MUOVERE LA PINZA ANCHE AVVITANDOLA E SVITANDOLA PER MUOVERLA LUNGO LA CORDA.

STEP 03



TENENDO LA CORDA, TIRARE CON DECISIONE LA BOCCOLA VERSO LA PINZA. QUANDO SI SENTIRÀ UN CLICK, SIGNIFICA CHE LA CORDA È BLOCCATA.

STEP 04



(OPZIONALE) TAGLIA LA CORDA IN ECCESSO LASCIANDO ALMENO 2 CM DI CORDA DALLA BOCCOLA PER FACILITARE I FUTURI SMONTAGGI.

STEP 05



### MODEL PERFORMANCE - HOW TO CHANGE ROPE LENGHT





PUSH THE ROPE OUT OF THE HANDLE.

STEP 01



HOLDING THE ROPE, PUSH THE BUSHING IN THE ARROW DIRECTION. THE GRIPPER IS NOW FREE TO MOVE.

STEP 02



MOVE THE GRIPPER TO SET THE DESIRED ROPE LENGHT. YOU CAN ALSO SCREW AND UNSCREW THE GRIPPER TO MOVE IT ALONG THE ROPE.

STEP 03



HOLDING THE ROPE WITH A HAND, PUSH FIRMLY THE BUSHING IN THE ARROW DIRECTION, INTO THE GRIPPER. YOU'LL HEAR A CLICK WHEN THE GRIPPER IS SUCCESSFULLY BLOCKED.

STEP 04



(OPTIONAL) CUT THE EXCESS ROPE BUT LEAVE AT LEAST 2 CM OF EXTRA ROPE FROM THE BUSHING, THIS WILL MAKE FUTURE CHANGES EASIER.

STEP 05

